

Updating your Cyrus Lyric/THREE

You will need:

- USB to mini-USB lead
- Windows PC or Mac computer
- Both firmware files downloaded onto on your computer and saved to the desktop, outside of any folder

Please follow the procedure below to update the firmware in your unit

During the update process, no sources, speakers, or other electronic equipment should be connected to the Lyric/THREE

Stage 1 of 2

- The Updater file must be unzipped and both files saved to your computer's desktop
- Remove the power from your Lyric/THREE. The mains power must be disconnected for at least five minutes.
- Locate the upgrade switch on the back as shown below:



- Apply a ballpoint pen or similar pointed object to the upgrade switch. The switch is not easy to feel but will be pressed if an object is inserted into the opening.
- Still holding the switch, connect the mains power and wait 10 seconds.
- The display on the front of the Lyric/THREE will light up, showing a blank screen. You can now release the upgrade switch.
- Connect the USB cable to an available socket on your computer.
- Connect the other end of the USB cable to the mini-USB input labelled 'Upgrade'. Run the file you downloaded earlier titled Updater. You will need to accept any security warnings that appear on your computer.

- **With Windows** - During the process, you will be prompted to 'Press any key to continue'.
- **With Mac** - Select 'Quit' once a 'Drive unmount was successful' message is displayed

- Wait until the file has successfully copied over (this may take up to 60 seconds and the process must be left to complete without being interrupted), then wait a further 60 seconds.
 - Remove the USB cable from Lyric/THREE, followed by the mains cable. Wait at least 30 seconds before proceeding to Stage 2.
-

Stage 2 of 2

- Connect your Lyric/THREE to mains power and to the same network as your computer (if it is not already connected), and switch it on.
- Leave the unit for 30 seconds for all network functions to fully initialise.
- Locate your unit's IP address. This can be found by selecting Menu > Setup > Network > Status. The IP address will be four numbers separated by a dot and usually starts 192.168.x.xxx.
- Open an internet browser window on your computer and in the address bar type in the IP address followed by /update.asp. It should then read (with your IP address where the x's are in this example): xxx.xxx.x.xxx/update.asp
- When the page loads, click 'Browse', select the .bcd file that you downloaded earlier and click 'Upload'.
- On the next screen, click 'OK' and the new firmware will be loaded onto your Cyrus Lyric. It is very important that both your computer and Lyric/THREE stay switched on and connected to the network while this is happening as interrupting the upload may cause permanent damage to your unit.
- When the upload is complete, a new web page will load. Please ignore the instructions on this page and simply remove and re-connect the power to your unit.
- Wait 30 seconds then select Menu > Setup > Factory Reset > Yes. Your unit will now be restored to full factory settings and the update process is now complete.