

## XR AMPLIFIERS

#### When to update?

Cyrus i7-XR, i9-XR and Pre-XR amplifiers feature userupgradable firmware via ports on the back panel.

Owners can check the Cyrus website for notification of updates or register their products to receive notification when updates are released.

#### Compatibility

The same firmware download is used for the i7-XR, i9-XR and Pre-XR models. The firmware can auto-detect the amplifier type and enable model specific features as required.

# COMPUTERS AND OPERATING SYSTEMS

Cyrus firmware upgrades are possible using a PC computer. No special app is required, just basic file management skills to download, copy, rename and delete files.

The screenshots in the example are of a computer using Windows File Explorer under Windows 10 operating system. Other operating systems, computers and file management apps will appear differently although the steps in the upgrade procedure will be the same.

### **TOOLS REQUIRED**

The amplifier will not require dismantling.


A mini-USB cable (not supplied) and the upgrade firmware will also be required.

# DOWNLOAD

Download the firmware you require from the Cyrus website at www.cyrusaudio.com.

The firmware file name should be in the format 'CW09\_UI\_1v4.bin' where the red numbers in the example will change to indicate the firmware version.

File name formats may change from time to time, but XR amplifier firmware will always be prefixed 'CW09' and will clearly include the version number.








### DISCONNECT

Disconnect all cables, including mains power from the amplifier.




# CONNECT


- 1 Press and hold the front panel rotary control.
- 2 While holding the rotary control, connect the mini-USB cable to the UPGRADE port on the back of the amplifier.
- 3 Release the rotary control.

It is not necessary to connect mains power.

The amplifier is now ready for upgrade.

Don't operate the amplifier controls in any way during update.





## UPGRADE

Follow the instructions on the next page to upgrade the firmware.








#### i7-XR, i9-XR, Pre-XR FIRMWARE UPDATE INSTRUCTIONS

#### RENAME


To update successfully the firmware file must be renamed as'firmware.bin'.

- Select the firmware file in the 'Downloads' folder and press F2 on the computer keyboard. *The file name will be highlighted.*
- Re-name the file to 'firmware.bin'.



### COPY

 Select the renamed 'firmware.bin' file in the Downloads folder and copy it (Ctrl+C).




## DELETE ORIGINAL

In a File Explorer window the amplifier should be visible as a drive titled 'CRP DISABLD'. On that drive should be a single file (the current firmware), titled 'firmware.bin'.

- Select the CRP DISABLD folder.
- Delete the firmware.bin file.




del



#### PASTE UPDATE

- Select the CRP DISABLD folder.
- Paste the new firmware into this folder (Ctrl+V).

You should see a progress bar as the file is copied.




# DELETE DOWNLOAD

To avoid confusion in any future updates, it's good practice to delete the download before proceeding.

- Return to the downloads folder.
- Highlight the 'firmware.bin' file.
- Press DELETE.

The firmware download will be deleted.





#### www.cyrusaudio.com



# DISCONNECT


• Disconnect the update cable.





# CONNECT POWER

Re-connect mains power.



# CHECK VERSION

- Power up the amplifier.
- Press 'i' on the remote control.

Confirm that the updated firmware version is listed on the display.

